



ELITEDRIVE

THROTTLE MASTER

Plug and Play Installation



1. Power Down the Vehicle for 15 minutes before installation *
2. Unplug the Original Connector
3. Insert the Elitedrive Adaptor into the Original Socket
4. Insert the Original Connector into the Elitedrive Adaptor
5. Stick the display on the dashboard where you like
6. Run the cable to the dashboard and plug it in

